




**PLAN VIEW**




**SIGNING LEGEND**




**SPEED HUMP SYMBOL**




**PROFILE SECTION A-A**



**LONGITUDINAL JOINT DETAIL**



**TRANSVERSE JOINT DETAIL**



**TYPICAL SECTION B-B**

**NOTES**

1. SIGNS ARE TO BE INSTALLED AT THE SAME TIME THE CONCRETE HUMPS ARE INSTALLED.
2. IN SOME SITUATIONS, A TRANSVERSE JOINT MAY BE LOCATED BEYOND THE EDGE OF THE SPEED HUMP, FOR EXAMPLE: TO REPLACE ADDITIONAL PAVEMENT OR TO MATCH UP TO AN EXISTING TRANSVERSE JOINT.

1	REVISION 1/13/2011	 CITY ENGINEER  PUBLIC WORKS DIRECTOR	CITY OF OMAHA PUBLIC WORKS DEPARTMENT	
			<b>SPEED HUMP DETAILS</b> <b>CONCRETE SPEED HUMP</b>	<b>STANDARD PLATE 6-90</b> SHEET 2/2 ISSUE DATE: ..... MAY 27, 2010